

UMTV Connecting and Programming Directions

What do I need to do to receive UMTV?

You need

- a TV that is cable ready (or a cable-ready DVD/VCR connected to a TV)
- a UMTV wall outlet (available in all Res Hall rooms)
- a coaxial cable

Connect one end of the coaxial cable into the UMTV wall outlet and the other end into either

- the input port on the back of your cable-ready TV
- or the input port on the back of your DVD/VCR
(Your DVD/VCR should be connected to your TV with another coaxial cable from the output port of the DVD/VCR to the input port of the TV)



Coaxial Cable

Then, make sure that your TV (DVD/VCR) is set to receive a cable signal.

How do I set my TV (DVD/VCR) to receive a cable signal?

Using your TV (DVD/VCR) remote, select SET-UP or MENU to prompt an on-screen display.

Select that your TV (DVD/VCR) be set to CATV, CABLE or STD, **not to** antenna or HRD.

How do I autoprogram my TV (DVD/VCR)?

After you have set your TV (DVD/VCR) to receive a cable signal, you will need to autoprogram it. (You may also need to autoprogram after a power outage or if the TV (DVD/VCR) has been unplugged.)

Using your TV (DVD/VCR) remote, select and run the autoprogram function.

Why am I only getting channels 2–36?

Make sure that you have properly hooked up your TV (DVD/VCR), set it to receive cable, and have properly run the autoprogram function. If you are still only receiving channels 2–36, it is possible that your TV (DVD/VCR) is limited to 36 channels. If so, you will need a fully cable-ready TV (DVD/VCR) to receive UMTV's full range of programming.

Why am I only getting channels 2–13?

If you are only getting channels 2–13, your TV (DVD/VCR) is probably set to receive an antenna signal and not a cable signal. See Step 2 above.

I lost the remote control to my TV (DVD/VCR) and am having problems programming it.

Some TVs (DVDs/VCRs) require the original remote control to access the on-screen programming features. If this is the case and you cannot access the on-screen programming features with a universal remote control, then you will need to consult your owner's manual and/or call the manufacturer to order a replacement remote control.